

	<b>Operating and Safety Instructions – Foldable Access Platform 15-1000-ULE2000</b>	<b>UM-4</b>
Prepared by: Kayrat Burov Approved by: Aleksei Männiste	Approved: 13.08.2025	Version 1



1. Take the removable handle from its designated storage place (a special holder on the container wall). ✘ It is a square pipe with an end cap, designed to apply physical force to the platform **without risk of injury or mechanical damage**.



2. Insert the handle into the designated slot on the platform and, while controlling the position of the platform, lift the locking latch. (Both positions are indicated in the photo.)



3. Carefully lower the platform floor, holding the handle.  
 ✔ The platform's weight should be controlled using the handle as a lever.  
 ✘ Do not place hands into gaps or hinges — there is a risk of finger pinching.  
**N.B.** All actions must be performed only while standing on the ground.

**⚠ PROHIBITED ACTIONS:**

- ✘ Lifting or lowering the platform without the removable handle
- ✘ Inserting hands into pivot joint areas
- ✘ Using the platform mesh as a gripping point

**✔ PERMITTED GRIP:**

- Only by the removable handle — a safe element
- Use both hands, standing to the side of the mechanism

**P.S. Folding the platform must be done in the exact reverse order**